

MDR-IF5000

SERVICE MANUAL

Ver 1.2 2004. 03

*US Model
Canadian Model
AEP Model
UK Model
E Model*



- MDR-IF5000 is the component model block one in MDR-DS5000.

COMPONENT MODEL NAME FOR MDR-DS5000

DIGITAL SURROUND PROCESSOR	DP-IF5000
CORDLESS STEREO HEADPHONES	MDR-IF5000

SPECIFICATIONS

Modulation System	Frequency modulation
Carrier wave frequency	Right channel 2.8 MHz Left channel 2.3 MHz
Frequency response	12 – 24,000 Hz
Power requirements	Rechargeable Ni-Cd batteries (supplied) or R6 (size AA) batteries (dry-cell or rechargeable, sold separately)
Mass	Approx. 280 g (including the supplied rechargeable Ni-Cd batteries)

Design and specifications are subject to change without notice.


Notes on Chip Component Replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

CORDLESS STEREO HEADPHONES

Inserting the batteries in the headphones

As shown in the illustration below, insert the two supplied rechargeable Ni-Cd batteries with the ⊕ and ⊖ ends in the correct direction.



When using optional batteries

You can use R6 (size AA) dry-cell batteries, Sony R6 (size AA) Ni-Cd batteries (NC-AA, NC-AAS), and R6 (size AA) nickel-hydrium batteries (NH-AA) with the headphones. Insert the batteries as shown above.

Usage times for dry-cell batteries

Battery type	Usage time
Sony Alkaline Battery LR6/AM3 (N)	Approx. 90 hours
Sony Manganese Battery R6P/SUM-3 (NS)	Approx. 45 hours


Usage times and charging times for Sony rechargeable batteries (sold separately)

Battery type	Usage time	Charging time*
Sony R6 (size AA) Ni-Cd Battery NC-AA (700 mAh)	Approx. 30 hours	Approx. 6 hours
Sony R6 (size AA) Ni-Cd Battery NC-AAS (1000 mAh)	Approx. 40 hours	Approx. 9 hours
Sony R6 (size AA) Nickel-hydrium Battery NH-AA (1450 mAh)	Approx. 60 hours	Approx. 10 hours

* Time to fully charge the battery when it is completely drained.

(Continued)

How to attach the battery cover when it has come off
As shown in the illustration, align A with A, and B with B, and then attach the cover in place.




When charging R03 (size AAA) batteries

The supplied battery charger can also charge Sony R03 (size AAA) Ni-Cd batteries (NC-AAA) and R03 (size AAA) nickel-hydrium batteries (NH-AAA).

When charging R03 (size AAA) batteries, push down the adjuster on the battery charger.

When charging R6 (size AA) batteries, flip up the adjuster.



Charging times for R03 (size AAA) rechargeable batteries


Battery type	Charging time*
Sony R03 (size AAA) Ni-Cd Battery NC-AAA (250 mAh)	Approx. 5 hours
Sony R03 (size AAA) Nickel-hydrium Battery NH-AAA (650 mAh)	Approx. 10 hours

* Time to fully charge the battery when it is completely drained.

Notes


- The supplied battery charger can charge Sony R6 (size AA) Ni-Cd batteries (NC-AA, NC-AAS) and Sony R6 (size AA) nickel-hydrium batteries (NH-AA). Never attempt to charge other types of rechargeable batteries or dry-cell batteries.
- Do not use Sony R6 (size AA) Ni-Cd batteries (NC-AA (HJ)).
- The Ni-Cd batteries should be replaced with new ones when they last only half the expected time when fully charged. Purchase either Sony R6 (size AA) Ni-Cd batteries (NC-AA, NC-AAS) or Sony R6 (size AA) nickel-hydrium batteries (NH-AA). You can order the batteries from the store where you made the purchase or at your nearest Sony dealer.

Adjust the volume.




To adjust the volume of headphones (sold separately) connected to the PHONES jack

Turn PHONES—LEVEL to adjust the volume.




Adjust the balance.




The headphones automatically turn off when they are taken off — Auto Power On/Off Function

When not using the headphones, be sure that the self-adjusting band is no longer pulled up. The power stays on when the self-adjusting band is pulled up.



To check the remaining battery power Pull up the self-adjusting band and check the POWER indicator. The batteries can be used when the POWER indicator lights red.

Charge the batteries or use dry-cell batteries if the POWER indicator is faint, the sound is distorted, or increased noise occurs.



After using the headphone system

Turn off the digital surround processor first before turning off the component connected to the digital surround processor. If you turn off the connected component first, the infrared beam is cut off and noise may be emitted (this is not a malfunction). Do not hang the headphones on the digital surround processor or other components. The Auto Power On Function may be inadvertently activated, using up the batteries.

Transition time between modes

When pressing buttons on the digital surround processor to change to new modes, the transition time between modes may vary. This is due to differences in program transmission between modes.

(Continued)

SECTION 2 DISASSEMBLY


- The equipment can be removed using the following procedure.

Set → Frame assy → Hanger (L) → Band Assy, Head
 → Frame assy → Hanger (R) → RX board → Band Assy, Head


Note : Follow the disassembly procedure in the numerical order given.

2-1. FRAME ASSY


- Remove the left and right ear pads in the same manner.




2-2. HANGER (L)




2-3. HANGER (R)



2-4. RX BOARD



2-5. BAND ASSY, HEAD



SECTION 3 ELECTRICAL ADJUSTMENTS


Notes:

1. These adjustments are performed in the order that they are described.
2. Adjustment and measurement are performed for each channel unless otherwise specified.
3. Adjustment is made for right channel first and then the left channel.
4. The power voltage at the headphones section is supplied with 1.2 V.
5. The processor section is used as jig to adjust the headphones section (MDR-IF5000).
6. Adjustment is made with the RX SW board and RX PD1 and RX PD2 boards (for both L-ch and R-ch) connected to the RX board with wires (normal part).

0 dB=0.775 V


Tuning Adjustment

Preparation:




1. Set the processor section (DP-IF5000) in test mode and operate the set to generate a signal of 1 kHz and -10 dB. (Refer to DP-IF5000 service manual page 7.)
2. Supply 1.2 V to between VCC and ground on the RX board.
3. Adjust RV11 (volume control) on the RX board to the minimum level.

Setting:




1. Connect a distortion meter to TP11 (L-ch) and TP9 (R-ch) on the RX board.
2. Adjust L34 and 35 for L-ch and L54 and 55 for R-ch on the RX board so that the reading on the distortion meter is minimized.

Adjustment Location:




SECTION 4
DIAGRAMS

4-1. BLOCK DIAGRAM



4-2. PRINTED WIRING BOARDS




Semiconductor Location	
Ref. No.	Location
D1	C-13
D2	F-13
D3	C-10
D4	F-10
D10	D-2
D51	D-5
D52	D-5
IC31	D-3
IC32	F-3
IC51	D-4
IC52	F-4
Q1	B-3
Q2	B-4
Q3	B-4
Q4	B-5

Note:

-  : parts extracted from the component side.
-  : Through hole.
-  : Pattern from the side which enables seeing.
-  : Pattern of the rear side.


4-3. SCHEMATIC DIAGRAM • Refer to page 13 for IC Block Diagrams.




- Note:**
- All capacitors are in μF unless otherwise noted. pF: μF 50 WV or less are not indicated except for electrolytics and tantalums.
 - All resistors are in Ω and $\frac{1}{4}\text{W}$ or less unless otherwise specified.
 - Δ : internal component.
 - $\square$: panel designation.
 - B+ : B+ Line.
 - $\square$: adjustment for repair.
 - Power voltage is dc 3 V and fed with regulated dc power supply from battery terminal.
 - Total current is measured with POWER ON (no-sig-nal) mode.
 - Voltage is dc with respect to ground under no-signal condition.
no mark : POWER ON
 - Voltages are taken with a VOM (Input impedance 10 M Ω). Voltage variations may be noted due to normal production tolerances.
 - Signal path.
 - $\Rightarrow$: RF
 - $\Rightarrow$: ANALOG

• IC Block Diagrams

IC31, 51 SC111711DR2



IC32, 52 MC34119DTBEL




SECTION 5
EXPLODED VIEW

NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Color Indication of Appearance Parts
Example :
KNOB, BALANCE (WHITE) ... (RED)
Parts Color Cabinet's Color



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	X-4951-063-1	BAND (F) ASSY, HEAD		* 16	1-671-719-11	RX PD2 BOARD (L-CH)	
2	X-4951-064-1	BAND (R) ASSY, HEAD		17	X-4951-066-1	LID (L) ASSY, HANGER	
3	7-685-104-19	SCREW +P 2X6 TYPE2 NON-SLIT		18	4-213-918-01	SPRING, TENSION	
4	X-4951-014-1	SUSPENDER ASSY		* 19	1-671-720-11	RX SW BOARD	
5	4-213-919-01	PLATE (L), FRONT		* 20	A-4542-557-A	RX BOARD, COMPLETE	
6	X-4950-548-1	FRAME (L) ASSY		21	X-4950-549-1	FRAME (R) ASSY	
7	4-213-911-01	PAD (OUTER), EAR		22	4-213-916-01	SCREEN	
8	4-213-910-01	PAD (INNER), EAR		23	4-213-920-01	PLATE (R), FRONT	
9	4-213-900-01	LID, BATTERY		24	4-213-897-01	HANGER (R)	
10	4-961-876-01	TERMINAL (COMMONNESS), BATTERY		25	4-213-899-01	LID (R), HANGER	
11	4-214-464-01	TERMINAL, (-) BATTERY		26	4-215-827-01	STOPPER, BAND	
12	4-961-874-01	TERMINAL, (+) BATTERY		* 27	1-671-718-11	RX PD1 BOARD (R-CH)	
13	4-213-896-01	HANGER (L)		* 28	1-671-719-11	RX PD2 BOARD (R-CH)	
14	4-213-901-01	WINDOW, RAY CATCHER		SP31	X-4951-065-1	DRIVER ASSY (L-CH)	
* 15	1-671-718-11	RX PD1 BOARD (L-CH)		SP51	X-4951-065-1	DRIVER ASSY (R-CH)	

SECTION 6 ELECTRICAL PARTS LIST

Ver 1.2

RX

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL: Metal-film resistor.
METAL OXIDE: Metal oxide-film resistor.
F: nonflammable

- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u : μ , for example:
uA.. : μ A.. uPA.. : μ PA..
uPB.. : μ PB.. uPC.. : μ PC.. uPD.. : μ PD..
- CAPACITORS
uF : μ F
- COILS
uH : μ H

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-4542-557-A	RX BOARD, COMPLETE *****		C65	1-135-201-11	TANTALUM CHIP 10uF 20%	4V
		< CAPACITOR >		C66	1-163-033-11	CERAMIC CHIP 0.022uF	50V
C1	1-163-031-11	CERAMIC CHIP 0.01uF	50V	C67	1-135-201-11	TANTALUM CHIP 10uF 20%	4V
C2	1-163-243-11	CERAMIC CHIP 47PF 5%	50V	C68	1-135-180-21	TANTALUM CHIP 3.3uF 20%	6.3V
C3	1-163-031-11	CERAMIC CHIP 0.01uF	50V			< DIODE >	
C4	1-163-031-11	CERAMIC CHIP 0.01uF	50V	D10	8-719-066-57	LED SA2512 (POWER)	
C5	1-163-031-11	CERAMIC CHIP 0.01uF	50V	D51	8-719-421-40	DIODE MA77	
				D52	8-719-421-40	DIODE MA77	
C6	1-164-346-11	CERAMIC CHIP 1uF	16V			< IC >	
C7	1-126-246-11	ELECT CHIP 220uF 20%	4V	IC31	8-759-473-72	IC SC111711DR2	
C8	1-164-346-11	CERAMIC CHIP 1uF	16V	IC32	8-759-347-33	IC NJM2113V-TE2	
C9	1-135-201-11	TANTALUM CHIP 10uF 20%	4V	IC51	8-759-473-72	IC SC111711DR2	
C30	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	IC52	8-759-347-33	IC NJM2113V-TE2	
						< COIL >	
C31	1-163-021-11	CERAMIC CHIP 0.01uF 10%	50V	L1	1-412-956-21	INDUCTOR 27uH	
C32	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	L32	1-412-957-11	INDUCTOR 33uH	
C33	1-163-106-00	CERAMIC CHIP 36PF 5%	50V	L33	1-239-762-11	FILTER, BAND PASS	
C34	1-164-346-11	CERAMIC CHIP 1uF	16V	L34	1-416-885-11	COIL, DETECTION (A)	
C37	1-163-031-11	CERAMIC CHIP 0.01uF	50V	L35	1-416-886-11	COIL, DETECTION (B)	
C38	1-163-031-11	CERAMIC CHIP 0.01uF	50V	L51	1-412-959-11	INDUCTOR 47uH	
C39	1-163-031-11	CERAMIC CHIP 0.01uF	50V	L52	1-412-957-11	INDUCTOR 33uH	
C40	1-163-031-11	CERAMIC CHIP 0.01uF	50V	L53	1-239-763-11	FILTER, BAND PASS	
C42	1-117-720-11	CERAMIC CHIP 4.7uF	10V	L54	1-416-887-11	COIL, DETECTION (A)	
C43	1-163-809-11	CERAMIC CHIP 0.047uF 10%	25V	L55	1-416-888-11	COIL, DETECTION (B)	
						< TRANSISTOR >	
C44	1-117-720-11	CERAMIC CHIP 4.7uF	10V	Q1	8-729-220-93	FET 2SK209-G	
C45	1-135-201-11	TANTALUM CHIP 10uF 20%	4V	Q2	8-729-024-13	TRANSISTOR 2SA1256E4	
C46	1-163-033-11	CERAMIC CHIP 0.022uF	50V	Q3	8-729-809-77	TRANSISTOR 2SC3142-J4	
C47	1-135-201-11	TANTALUM CHIP 10uF 20%	4V	Q4	8-729-216-22	TRANSISTOR 2SA1162-G	
C48	1-135-180-21	TANTALUM CHIP 3.3uF 20%	6.3V			< RESISTOR >	
C50	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	R1	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
C51	1-163-021-11	CERAMIC CHIP 0.01uF 10%	50V	R2	1-216-049-11	RES,CHIP 1K 5%	1/10W
C52	1-163-121-00	CERAMIC CHIP 150PF 5%	50V	R3	1-216-097-00	RES,CHIP 100K 5%	1/10W
C53	1-163-031-11	CERAMIC CHIP 0.01uF	50V	R4	1-216-093-00	RES,CHIP 68K 5%	1/10W
C54	1-163-031-11	CERAMIC CHIP 0.01uF	50V	R5	1-216-049-11	RES,CHIP 1K 5%	1/10W
C55	1-163-123-00	CERAMIC CHIP 180PF 5%	50V	R6	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
C56	1-163-123-00	CERAMIC CHIP 180PF 5%	50V	R7	1-216-037-00	METAL CHIP 330 5%	1/10W
C57	1-163-031-11	CERAMIC CHIP 0.01uF	50V	R8	1-216-001-00	METAL CHIP 10 5%	1/10W
C58	1-163-031-11	CERAMIC CHIP 0.01uF	50V	R34	1-216-063-00	RES,CHIP 3.9K 5%	1/10W
C59	1-163-031-11	CERAMIC CHIP 0.01uF	50V	R35	1-216-063-00	RES,CHIP 3.9K 5%	1/10W
C60	1-163-031-11	CERAMIC CHIP 0.01uF	50V				
C61	1-135-149-21	TANTALUM CHIP 2.2uF 20%	10V				
C62	1-117-720-11	CERAMIC CHIP 4.7uF	10V				
C63	1-163-809-11	CERAMIC CHIP 0.047uF 10%	25V				
C64	1-117-720-11	CERAMIC CHIP 4.7uF	10V				

MDR-IF5000

RX	RX PD1	RX PD2	RX SW
----	--------	--------	-------

Ref. No.	Part No.	Description	Remark		
R36	1-216-049-11	RES,CHIP	1K	5%	1/10W
R37	1-216-073-00	METAL CHIP	10K	5%	1/10W
R38	1-216-089-00	RES,CHIP	47K	5%	1/10W
R39	1-216-063-00	RES,CHIP	3.9K	5%	1/10W
R40	1-216-063-00	RES,CHIP	3.9K	5%	1/10W
R51	1-216-037-00	METAL CHIP	330	5%	1/10W
R52	1-216-097-00	RES,CHIP	100K	5%	1/10W
R53	1-216-111-00	METAL CHIP	390K	5%	1/10W
R54	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R55	1-216-063-00	RES,CHIP	3.9K	5%	1/10W
R56	1-216-049-11	RES,CHIP	1K	5%	1/10W
R57	1-216-073-00	METAL CHIP	10K	5%	1/10W
R58	1-216-089-00	RES,CHIP	47K	5%	1/10W
R59	1-216-063-00	RES,CHIP	3.9K	5%	1/10W
R60	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
< VARIABLE RESISTOR >					
RV10	1-223-516-11	RES, VAR, CARBON	50K (BALANCE)		
RV11	1-223-517-11	RES, VAR, CARBON	50K/50K (VOL)		

*	1-671-718-11	RX PD1 BOARD (L-CH)	*****		
< PHOTO DIODE >					
D1	8-719-058-49	PHOTO DIODE	PP508		

*	1-671-718-11	RX PD1 BOARD (R-CH)	*****		
< PHOTO DIODE >					
D3	8-719-058-49	PHOTO DIODE	PP508		

*	1-671-719-11	RX PD2 BOARD (L-CH)	*****		
< PHOTO DIODE >					
D2	8-719-058-49	PHOTO DIODE	PP508		

*	1-671-719-11	RX PD2 BOARD (R-CH)	*****		
< PHOTO DIODE >					
D4	8-719-058-49	PHOTO DIODE	PP508		

Ref. No.	Part No.	Description	Remark
*	1-671-720-11	RX SW BOARD	*****
< SWITCH >			
S10	1-572-467-61	SWITCH, PUSH (1 KEY) (POWER)	*****
MISCELLANEOUS			

SP31	X-4951-065-1	DRIVER ASSY (L-CH)	
SP51	X-4951-065-1	DRIVER ASSY (R-CH)	

MEMO

REVISION HISTORY

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the upper on the revised page allows you to jump to the next revised page.

[illegible]